## **Continuum Mechanics**

Lecture 15 - Experimental Rheology

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

5 November, 2020

1

#### schedule

- 5 Nov Experimental Rheology
- 10 Nov Energy, Rotation, Vorticity
- 12 Nov Compressible Flow, HW8 Due
- 17 Nov Non-Newtonian Fluids




Figure 1: Plane Couette flow

## plane couette flow

- Steady unidirectional flow of an incompressible fluid between two horizontal plates with no pressure gradient in the flow direction is known as plane Couette flow
- one plate is fixed and the other moves with a constant velocity v<sub>0</sub>
- From the continuity equation

$$v_i = \langle v(x_2), 0, 0 \rangle$$

From Navier-Stokes we find

$$v(x_2) = \frac{v_0 x_2}{d}$$

3

#### plane poiseuille flow

- · Steady, unidirectional flow between two fixed plates
- Initial form for  $v_i$  is same as plane Couette flow
- Navier-Stokes gives

$$\frac{\partial p}{\partial x_1} = \mu \frac{d^2 v}{dx_2^2}$$
$$\frac{\partial p}{\partial x_2} = 0$$
$$\frac{\partial p}{\partial x_3} = 0$$

5

# plane poisseuille flow




Figure 2: plane Poiseuille flow

#### hagen-poiseuille flow

Steady, unidirectional axisymmetric flow in a circular cylinder


$$v_r = v_\theta = 0, \qquad v_z = v(r)$$

• From the Navier-Stokes equations, we find

$$\begin{split} \frac{\partial p}{\partial r} &= 0\\ \frac{\partial p}{\partial \theta} &= 0\\ -\frac{\partial p}{\partial z} &+ \mu \left[ \frac{1}{r} \frac{d}{dr} \left( r \frac{dv}{dr} \right) \right] &= 0 \end{split}$$

example

• Find the velocity field if there are two fluids (in layers) in plane couette flow



7

#### couette flow

- Laminar, steady flow of an incompressible fluid between two rotating coaxial cylinders is called Couette flow
- The velocity field has the form

$$v_r = 0,$$
  $v_\theta = v(r),$   $v_z = 0$ 

Continuity is automatically satisfied, Navier-Stokes gives

$$\frac{d^2v}{dr^2} + \frac{1}{r}\frac{dv}{dr} - \frac{v}{r^2} = 0$$

9

#### couette flow




Figure 3: couette flow

# oscillating plane

• Flow near an oscillating plane will have the form

$$v_i = \langle v(x_2, t), 0, 0 \rangle$$

• The only non-trivial Navier-Stokes equation gives

$$\rho \frac{\partial \mathbf{v}}{\partial t} = \mu \frac{\partial^2 \mathbf{v}}{\partial \mathbf{x}_2^2}$$

Which has the solution

$$v = ae^{-\beta x_2}\cos(\omega t - \beta x_2 + \epsilon)$$

rotational cylinder

# $\tau = \mu \frac{du}{dy} \approx \mu \frac{\Omega r}{h}$ Note that $M = \int dM = \int r r dA$ $M = \int dM = \int r r dA$ Viscous Fluid $\mu$ $dA = 2\pi r dr$ $dA = 2\pi r dr$ Viscous Solid cylinder

Figure 4: rotating cylinder viscometer

#### rotational cylinder

- Couette flow with one of the cylinders fixed
- Shear rate is applied through a constant angular velocity of one of the cylinders
- Torque on the other cylinder is measured
- Used for fluids with very low viscosity

13

# cone and plate




Figure 5: Cone and plate rheometer

#### cone and plate

- One of the two plates is held fixed and torque is measured
- The other rotates at an applied angular velocity
- Cones are used to provide a constant shear rate, also use less fluid volume
- Parallel plates are more flexible in the spacing, also used for very temperature-sensitive tests

15

# capillary rheometer




Figure 6: capillary rheometer

### capillary rheometer

- Used for testing higher shear-rates than rotational rheometers
- Commonly used for polymers (which are non-newtonian and have rate-dependent viscosity)
- Usually flow-rate is controlled and pressure drop is measured (but either can be controlled)
- Flow-rate can be converted to find the shear-rate, pressure drop can be converted to shear stress

17

# dynamic

- For materials which are viscoelastic, dynamic tests are used
- Either an oscillating rotational rheometer (for more liquid)
- Or an oscillating tensile test (for more elastic materials)

#### extensional rheometry




Figure 7: extensional rheometry

19

## extensional rheometry

- Another common test for polymer melts and viscoelastic materials
- Extensional viscosity is a function of both the applied stretch rate and the total deformation of the material
- Extrusion-based processes depend on extensional viscosity

- Find velocity field of water pumped up a hill through a narrow channel
- Slope of channel is 45°
- Assume the only body forces present are due to gravity
- Note: solution will be in terms of pressure

21

#### group 2


• Given the following polar coordinate velocity field


$$v_r = \frac{Q}{2\pi r}$$
  $v_\theta = 0$ 

• Find the streamline passing through some arbitrary point  $(r_0, \theta_0)$  and the pathline originating from  $(R, \Theta)$  at t = 0

# group 3

- A slender U-tube moves to the right with some acceleration. a.
- Find the relation between a, the width of the tube, I and the difference in height levels of water at different ends of the tube, h





23

# reading

■ pp 375-402