

## Lecture 17 - Non-Newtonian Fluids

Dr. Nicholas Smith

Wichita State University, Department of Aerospace Engineering

17 November, 2020

1

## schedule

- 17 Nov - Non-Newtonian Fluids
- 1 Dec - Final Review, Research Project, HW9 Due
- 3 Dec - Final Review

2

- non-newtonian fluids
- maxwell fluid
- other viscoelastic models
- dynamic properties
- time temperature superposition
- boltzman superposition
- experimental characterization

## non-newtonian fluids

- For a fluid to be Newtonian we assumed that  $T'_{ij}$  is linearly dependent on  $D_{ij}$  and nothing else
- In many fluids  $T'_{ij}$  is not linearly dependent on  $D_{ij}$
- These fluids are most commonly referred to as shear-thinning or shear-thickening fluids
- Their viscosity is a function of the strain-rate applied

## shear thinning fluids

- Shear-thinning fluids decrease in viscosity with an increase in strain-rate
- Some examples are ketchup, paint, whipped cream, quicksand and blood
- Shear-thinning is generally only an effect in complex fluids (polymers and solutions)
- At the molecular level, research is still being done to discover why a fluid would be shear-thinning

5

## shear-thickening fluids

- Shear-thickening fluids increase viscosity with an increased strain-rate
- Generally occurs in suspensions (many polymer melts are suspensions)
- Cornstarch and water, silica and polyethylene glycol
- Uses include body armor and brake pads

6

- Many non-newtonian fluids have a viscosity which does not depend on the history, only on the current shear-rate
- In this case, the fluid can be modeled as a generalized Newtonian fluid

$$T'_{ij} = \mu(D_{ij})D_{ij}$$

- Some common models for  $\mu(D_{ij})$  are Power-Law, Cross, and Carreau

7

## linear viscoelasticity

- We discussed fluids where  $T'_{ij}$  is not linearly dependent on  $D_{ij}$ , but if  $T'_{ij}$  depends on some other measure (such as strain), the fluid is also non-newtonian
- Linear viscoelastic materials have a linear dependence on  $D_{ij}$ , but also depend on  $E_{ij}$
- Viscoelasticity can be used to model behavior in both liquids (die swell in polymer melts) and solids (creep and stress relaxation)

8

## maxwell fluid

- In general, a Maxwell fluid is defined by the constitutive equation

$$T_{ij} = -p\delta_{ij} + S_{ij}$$

- Where  $S$  is the “extra stress”

$$S_{ij} + \lambda \frac{\partial S_{ij}}{\partial t} = 2\mu D_{ij}$$

- In 1D, a Maxwell fluid can be considered as a spring and dashpot connected in series

9

## maxwell fluid




Figure 1: image

10

## creep

- We can model the creep behavior of a 1D Maxwell fluid by considering a constant applied force,  $F_0$
- For a 1D Maxwell fluid we have

$$F + \lambda \frac{dF}{dt} = \eta \frac{d\epsilon}{dt}$$

- If  $F = F_0$ , then  $\frac{dF}{dt} = 0$  so we have

$$F_0 = \eta \frac{d\epsilon}{dt}$$

- So the strain will be given by

$$\epsilon = \int \frac{F_0}{\eta} dt = \frac{F_0}{\eta} t + \epsilon_0$$

11

## creep

- Since  $\epsilon_0$  represents the initial strain, we can write  $\epsilon_0 = F_0/G$  where  $G$  is the spring constant
- In shear the creep compliance is often called  $J(t)$ , and represents the strain divided by the applied force
- For this fluid the creep compliance function is

$$J(t) = \frac{\epsilon}{F_0} = \frac{1}{\eta} t + \frac{1}{G}$$

12

## stress relaxation

- To model stress relaxation, we consider a constant applied strain,  $\epsilon_0$ , and see what effect that has on the stress
- In this case  $\frac{d\epsilon}{dt} = 0$  and we have

$$F + \lambda \frac{dF}{dt} = 0$$

- solving this differential equation gives

$$F = F_0 e^{-tG/\eta} = G\epsilon_0 e^{-tG/\eta}$$

- The stress relaxation function,  $\phi(t)$  is  $F/\epsilon_0$  which gives

$$\phi(t) = G e^{-tG/\eta}$$

13

## notation

- Creep and stress relaxation work often uses a different notation than what we are accustomed to
- $J(t)$  is shear creep compliance,  $D(t)$  is tensile creep compliance
- Compliance is most commonly used, but sometimes  $G(t)$  for shear stiffness and  $E(t)$  for tensile stiffness are used
- Due to the time history dependence, in general

$$G(t) \neq 1/J(t)$$

14

## example

- A rod is initially 12" long and 2" in diameter
- Find the stretch after a 20 lb weight is hung for 24 hours
- Tensile compliance is given by

$$D = 0.5 - \exp(-0.03t) \text{ Mpsi}^{-1}$$

15

## solids

- A Maxwell fluid has an elastic portion, but behaves mostly like a fluid
- Many viscoelastic models are for solids, which have some viscous or damping behavior, but are mostly solid-like
- The Kelvin-Voigt model connects a spring and dashpot in parallel, and is the simplest form of viscoelastic model for solids

16






Figure 2: image

17

## zener model

- Both the Maxwell and Kelvin-Voigt models are overly simple to describe many real viscoelastic materials
- The Zener model combines the two, it can be viewed either as a spring in series with a Kelvin-Voigt solid or as a spring in parallel with a Maxwell fluid
- Also called a standard linear solid
- Can be further extended for polymers with a distribution of relaxation times
- Multiple Kelvin-Voigt elements are connected in series, with a spring connected in series

18




Figure 3: image

19

## dynamic properties

- You have probably noticed that plastic cups do not ring as long as glasses or metal objects
- This is due to the damping properties of viscoelastic materials
- Polymers are often used to dampen vibrations for this reason
- Damping will vary with frequency, we can model the effects

20

## dynamic properties

- If we assume some sinusoidal applied strain,  
 $\epsilon(t) = \epsilon_0 \sin \omega t$
- In general, the viscoelastic stress response will be out of phase

$$\sigma = \sigma_0 \sin(\omega t + \delta)$$

- We can re-write this as

$$\sigma = (\sigma_0 \cos \delta) \sin \omega t + (\sigma_0 \sin \delta) \cos \omega t$$

21

## dynamic properties

- We can further re-write the equation in terms of a so-called “storage modulus” and “loss modulus”

$$\sigma = \epsilon_0 [E' \sin \omega t + E'' \cos \omega t]$$

- The storage modulus,  $E'$  corresponds to the elastic response
- The loss modulus,  $E''$  corresponds to the viscous response

22

## complex representation

- The dynamic response is analogous to electric circuits, and can be expressed in a similar fashion using a complex representation

$$\epsilon^* = \epsilon_0 \exp i\omega t$$

$$\sigma^* = \sigma_0 \exp i(\omega t + \delta)$$

- This gives the complex modulus as

$$\begin{aligned} E^* &= \sigma^* / \epsilon^* \\ &= \frac{\sigma_0}{\epsilon_0} \exp i\delta \\ &= \frac{\sigma_0}{\epsilon_0} (\cos \delta + i \sin \delta) \\ &= E' + iE'' \end{aligned}$$

23

## damping

- We can characterize the amount of damping in a viscoelastic material with  $\delta$

$$\tan \delta = \frac{D''}{D'} = \frac{E''}{E'}$$

- When  $\delta = 0$  there is no viscous damping (most metals have  $\delta \approx 0$ )
- Polymers in certain temperature ranges can have  $\delta$  as high as  $30^\circ$
- Note: at the same temperature and frequency,  $E^* = 1/D^*$  and  $G^* = 1/J^*$

24

- Consider the same bar as before (12" long and 2" in diameter)
- The bar is subjected to a sinusoidal force with  $F_0 = 50$  lbs and 80 Hz.

$$D'' = 40 \text{ ksi}$$

25

## temperature dependency

- In both the time and frequency domain, many viscoelastic materials are temperature dependent
- In terms of our 1D models, the viscous portion is much more temperature dependent than the elastic portion
- The two most common models of temperature dependence are the Arrhenius model and the Williams-Landel-Ferry (WLF) model

26

## time-temperature




Figure 4: image

27

## frequency-temperature




Figure 5: image

28

## temperature shift

- Both Arrhenius and WLF models use the parameter  $a_T$  as the temperature shift
- $a_T = a_T(T, T_0)$
- For compliance ( $J$  and  $D$ )

$$J^{T_0}(t) = J^T(a_T t)$$

- And for stiffness ( $G$  and  $E$ )

$$D^{T_0}(t) = D^T\left(\frac{t}{a_T}\right)$$

29

## arrhenius

- The Arrhenius function only uses one curve-fit parameter

$$a_T = \exp\left(\frac{\Delta H}{R} \left[\frac{1}{T} - \frac{1}{T_R}\right]\right)$$

- $R$  is the universal gas constant
- Theoretically,  $\Delta H$  is the activation enthalpy of the relaxation
- $T$  is the temperature and  $T_0$  is the reference temperature
- Popular model because the constants have some physical meaning, but they are still curve fit

30

- The Williams-Landel-Ferry model is given by

$$\log(a_T) = \frac{-C_1(T - T_R)}{C_2 + (T - T_R)}$$

- $C_1$  and  $C_2$  are the curve-fit parameters
- Most optimization algorithms perform poorly with exponential functions, so it is best to solve for  $\log(a_T)$

31

## characterization example

rendered version of example can be found at [here](#)

32



## boltzman superposition

- What if we had one load applied at  $t_0 = 0$ , we would have

$$\epsilon_0 = \sigma_0 D(t)$$

- And some other load applied at  $t_1$  would give

$$\epsilon_1 = \sigma_1 D(t - t_1)$$

- Thus the total strain would be:

$$\epsilon = \epsilon_0 + \epsilon_1 = \sigma_0 D(t) + \sigma_1 D(t - t_1)$$

33

## boltzman superposition

- For  $N$  applied loads, we have

$$\epsilon(t) = \Delta\sigma_1 D(t - t_1) + \Delta\sigma_2 D(t - t_2) + \dots + \Delta\sigma_N D(t - t_N)$$

- For some general, arbitrary loading function, this gives

$$\epsilon(t) = \int_0^t D(t - u) \frac{d\sigma}{du} du$$

34

## example

- For example, when we apply a load and then remove it, we have

$$\epsilon(t) = \sigma_0 D(t) - \sigma_0 D(t - t_1)$$

- If we consider  $D = 1.2t^{0.1} \text{ GPa}^{-1}$  and let  $\sigma_0 = 1 \text{ MPa}$  and  $t_1 = 1 \text{ s}$ , then we have

$$\epsilon(t) = (1.2t^{0.1} - 1.2(t - 1)^{0.1})$$

35

## example





Figure 6: image

36



**Figure 7:** image

37

## experimental characterization

- In practice, both the dynamic properties and time-temperature superposition are often used to characterize viscoelastic materials
- Dynamic experiments are much faster than creep experiments, and can give the same information
- There are physical limitations to the frequencies that can be applied
- To go beyond those frequencies, a range of temperatures are tested
- This can typically be done using a Dynamic Mechanical Analyzer (DMA)

38

- To characterize a viscoelastic material in a DMA, tests are run over a range of frequencies
- At each frequency we measure both the stress and strain
- Plotting both, we can find the complex modulus (or compliance) at that frequency
- Over a range of frequencies this gives the complex modulus as a function of frequency
- Only a few cycles are needed to fit the curve

39

## other considerations

- When creep and/or stress relaxation experiments must be done, time-temperature superposition can still be used
- Creep or relaxation experiments are run under various temperatures, as in our example

40